## Pent Summer House Assembly Manual

**Pressure Treated Tanalised Timber for Longer Lasting Life!** 

# Ready To Build - 4ft Range

#### Thank you for purchasing your Total Shed.

All of our sheds are made from only the finest selected timber which are (Tanalised), specially pressure treated for a longer and lasting durable life span to the elements.

Each shed is carefully packed and delivered on a pallet ready to be assembled.

## FEATURES NEW FLEXIBLE, INTER-CHANGEABLE DESIGN FOR YOUR INDIVIDUAL STYLE.

**2 Persons Recommended for Assembling Shed** Tools Required:



HAMMER



) ( , sta



V STANLEY KNIFE

PLEASE NOTE: Use extreme caution when using any tools. Always wear safety gear where necessary. It is advisable that at least 2 or more persons assemble the shed for health and safety purposes. We are not responsible for any injuries caused whilst assembling this shed.





DELIVERED FLAT PACKED IN EASY TO INSTALL SECTIONS

Featured Build of the Pent 10x4ft Summer House

Check List: See your shed size for details. Your delivery should contain the following:

## FLEXIBLE, INTER-CHANGEABLE **PANELS** FOR YOUR INDIVIDUAL STYLE AND PREFFERENCE.

If you are thinking of mixing it up then there are just a few key points to bare in mind.

4ft Door Panel will always be in the on the Left side of the build. Any smaller available panels such as 2ft will always be at the end on the right side.

Take a few moments to study the manual and get an idea of how your shed should look like after each step.

Pent Summer House **4ft Range** 

8x4ft Pack

**x2** Floor (4x4)

☐ **x2** Pent Roof (4x4)

☐ **x2** Pent Roof Top (4ft)

x4 Blank Panels (4ft Wide)

☐ **x1** Window Panel (4ft Wide)

**x2** Pent Angle Tops (4ft)

**x2** Floor Blocks (4ft)

x2 Overhang (4ft)

**x6** Felt Strips (4ft)

☐ **x2** Felt Strips (1ft)

☐ **x6** Corner Strips

☐ **x2** Roof Felt (9ft)

☐ **x1** Fixing Kit

**x2** Diamond Caps

☐ Instruction Manual

(Found in the polytube pack)

x2 Add-On

□ x1 Door Panel □ Single □ Double

## 4x4ft Pack

- $\square$  **x1** Floor (4x4)
- ☐ **x1** Pent Roof (4x4)
- ☐ **x1** Pent Roof Top (4ft)
- ☐ **x2** Blank Panels (4ft Wide)
- □ **x1** Door Panel □ Single □ Double
- **□ x1** Window Panel (4ft Wide)
- **x2** Pent Angle Tops (4ft)
- **x2** Floor Blocks (4ft)
- x2 Add-On
- **x4** Felt Strips (4ft)
- **x2** Felt Strips (1ft)
- **x4** Corner Strips
- ☐ **x1** Overhang (4ft)
- ☐ **x2** Roof Felt (5ft)
- ☐ **x1** Fixing Kit (Found in the polytube pack)



Checked and Signed by:

☐ **x2** Roof Felt (11ft)

☐ Instruction Manual

(Found in the polytube pack)

**x1** Fixing Kit

## 10x4ft Pack

- ☐ **x2** Floor (4x4)
- ☐ **x1** Floors (2x4)
- ☐ **x2** Pent Roof (4x4)
- $\square$  **x1** Pent Roofs (2x4)
- ☐ **x2** Pent Roof Top (4ft)
- ☐ **x1** Pent Roof Tops (2ft)
- **x4** Blank Panels (4ft Wide)
- ☐ **x1** Blank Panels (2ft Wide)
- ☐ **x1** Door Panel ☐ Single ☐ Double
- □ **x1** Window Panel (4ft Wide)
- ☐ **x1** Window Panel (2ft Wide)
- **x2** Pent Angle Tops (4ft)
- **x2** Floor Blocks (4ft)
- ☐ **x2** Overhangs (4ft)
- ☐ **x1** Overhang (2ft)
- x2 Add-On
- ☐ **x6** Felt Strips (4ft)
- **x2** Felt Strips (2ft)
- **x2** Felt Strips (1ft)
- **x8** Corner Strips
- x4 Diamond Caps



## 6x4ft Pack

- $\square$  **x1** Floor (4x4)
- ☐ **x1** Floors (2x4)
- ☐ **x1** Pent Roof (4x4)
- ☐ **x1** Pent Roofs (2x4)
- ☐ **x1** Pent Roof Top (4ft) ☐ **x1** Pent Roof Tops (2ft)
- ☐ **x3** Blank Panels (4ft Wide)
- □ **x1** Blank Panels (2ft Wide)
- □ x1 Door Panel □ Single □ Double
- **x1** Window Panel (2ft Wide)
- **x2** Pent Angle Tops (4ft)
- ☐ **x2** Floor Blocks (4ft)
- **x4** Felt Strips (4ft) **x2** Felt Strips (2ft)
- ☐ **x2** Felt Strips (1ft) x1 Overhang (4ft)
- ☐ **x1** Overhang (2ft)
- ☐ **x6** Corner Strips
- **x2** Diamond Caps
- **☐ x2** Roof Felt (7ft)
- □ x2 Add-On

- x1 Fixing Kit
  (Found in the polytube pack)
- ☐ Instruction Manual



Checked and Signed by:

## 12x4ft Pack

- **x3** Floor (4x4)
- ☐ **x3** Pent Roof (4x4)
- ☐ **x3** Pent Roof Top (4ft)
- □ **x5** Blank Panels (4ft Wide)
- □ **x1** Door Panel □ Single □ Double
- **x2** Window Panel (4ft Wide)
- **x2** Pent Angle Tops (4ft)
- **x3** Overhangs (4ft)
- □ **x2** Add-On
- **x2** Floor Blocks (4ft)
- **x8** Felt Strips (4ft)
- **x2** Felt Strips (1ft)
- ☐ **x8** Corner Strips
- ☐ **x4** Diamond Caps
- ☐ **x2** Roof Felt (13ft)
- ☐ x1 Fixing Kit
- (Found in the polytube pack)
- ☐ Instruction Manual



## 14x4ft Pack

- ☐ x3 Floors (4x4)
- ☐ **x3** Pent Roofs (4x4)
- ☐ **x1** Pent Roof (2x4)
- ☐ **x3** Pent Roof Tops (4ft)
- ☐ **x1** Pent Roof Top (2ft)
- x5 Blank Panels (4ft Wide)
- ☐ **x1** Blank Panels (2ft Wide)
- ☐ x1 Door Panel ☐ Single ☐ Double
- **x2** Window Panels (4ft Wide)
- x1 Window Panel (2ft Wide)
- ☐ **x2** Pent Angle Tops (4ft)
- x2 Floor Blocks (4ft)
- **x3** Overhang (4ft) **x1** Overhangs (2ft)
- x2 Add-On
- **x8** Felt Strips (4ft)
- x2 Felt Strips (2ft)
- **x2** Felt Strips (1ft) **x10** Corner Strips
- **x6** Diamond Caps

- ☐ **x2** Roof Felt (15ft)
- ☐ x1 Fixing Kit
  - (Found in the polytube pack)
- ☐ Instruction Manual



Checked and Signed by:

## 18x4ft Pack

- ☐ **x1** Floors (2x4)
- ☐ **x4** Pent Roofs (4x4)
- $\square$  **x1** Pent Roof (2x4)
- ☐ **x4** Pent Roof Top (4ft)
- ☐ **x1** Pent Roof Tops (2ft)
- ☐ **x6** Blank Panels (4ft Wide)
- □ **x1** Blank Panel (2ft Wide)
- □ x1 Door Panel □ Single □ Do
- **x3** Window Panels (4ft Wide)
- x1 Window Panel (2ft Wide)
- ☐ **x2** Pent Angle Tops (4ft)
- x2 Floor Blocks (4ft)
- x4 Overhangs (4ft)
- □ **x1** Overhangs (2ft)
- x2 Add-On
- ☐ **x10** Felt Strips (4ft)
- ☐ **x2** Felt Strips (1ft)
- x12 Corner Strips
- x8 Diamond Caps
- ☐ **x2** Roof Felt *(19ft)*

- **x1** Fixing Kit (Found in the polytube pack)
- ☐ Instruction Manual



## 16x4ft Pack

- $\square$  **x4** Pent Roof (4x4)
- ☐ **x4** Pent Roof Top (4ft)
- ☐ **x6** Blank Panels (4ft Wide)
- **x1** Door Panel Single Double
- ☐ **x3** Window Panel (4ft Wide)
- ☐ **x2** Pent Angle Tops (4ft)
- **x2** Floor Blocks (4ft)
- x4 Overhangs (4ft)
- x2 Add-On
- ☐ **x10** Felt Strips (4ft)
- ☐ **x2** Felt Strips (1ft)
- x10 Corner Strips
- ☐ x6 Diamond Caps
- ☐ x2 Roof Felt (17ft)
- x1 Fixing Kit
  (Found in the polytube pack)
- ☐ Instruction Manual



Checked and Signed by:

## 20x4ft Pack

- ☐ **x5** Pent Roof (4x4)
- ☐ **x5** Pent Roof Tops (4ft)
- ☐ **x7** Blank Panels (4ft Wide)
- ☐ x1 Door Panel ☐ Single ☐ Double
- **x4** Window Panel (4ft Wide)
- **x2** Pent Angle Tops (4ft)
- ☐ **x2** Floor Blocks (4ft)
- x5 Overhangs (4ft)
- x2 Add-On
- ☐ **x12** Felt Strips (4ft)
- ☐ **x2** Felt Strips (1ft)
- ☐ **x12** Corner Strips
- x8 Diamond Caps
- x2 Roof Felt (21ft)
- x1 Fixing Kit
  (Found in the polytube pack)
- ☐ Instruction Manual



Checked and Signed by:

CONTENTS				
01	Shed Range & List of Parts 4x6ft to 12x6ft	09	Step 10 & Step 11	- 2ft Window Panel - Side Pent Angle Tops
02	Shed Range & List of Parts 14x6ft to 20x6ft	10	Step 12 & Step 13	- Pent Front Tops - Side & Corner Strips
03	List of Contents	11	Step 14 & Step 15	- Pent Roof Panel Arrangement - Roof Overhangs
04	Pre-Assembly & Step 1 - Unpacking - Base Preparation Guidelines	12	Step 16 & Step 17	- Roof Add-On - Roof Felt Instructions
05	Step 2 & Step 3  - Floor & Block Ends - 4ft Left Side Panel	13	Step 18 & Step 19	- Felt Trim - Diamond Caps (Optional)
06	Step 4 & Step 5 - Rear Panels			
07	Step 6 & Step 7 - 2ft Rear Panel - 4ft Right Panel			
08	Step 8 & Step 9  - Door Panel - 4ft Window Panel			

## **PRE-ASSEMBLY**


### **Unpacking your Parts**

Unpack all of the components and check that you have all the parts required. Please use the checklist on previous page.

Carefully dispose of the delivery pallet and any excess timber.

Advisable: The underside of the floor must be treated with a quality wood preserver.

#### **SET THE SHED FOUNDATION**



## STEP • 1

Recommended: Paint shed in an oil based treatment to prevent water ingress into the timber. Also silicon your windows (Must silicon inside & outside) to prevent rain water seeping through the gaps between glass and the timber.

NO GOOD SLABS

NO GOOD SOIL



#### **SHED FLOOR:** Setting Shed Base

PLEASE NOTE: All Shed Floors Start with 4ft x 6ft Floor on the left side of the shed. Any 2ft x 6ft Floor Sections will always be at the right side on the end of the shed. 1a. Place the Floor panels with the Frame work pointing forwards (as shown in below) then screw together using screws provided at the end of the bearer points.

Use RED areas as joining points.


**1b.** Repeat this process for all other sheds in similar fashion.

**1c.** Check that all floor sections are securely attached and in a straight line to avoid any problems later on the build stage.

Use a Spirit Level for accuracy

**1d.** Secure the floor sections together by screwing the floor bearers at each end where they meet as shown in diagram 1d.





## STEP • 3

#### **IMPORTANT**

All Sheds With 3 or More Floor Pannels have the smallest Floor Panel on the Right End.

As shown on this diagram.



#### **FLOOR & BLOCK ENDS**


Add the Floor Block Ends (Heavy Duty Posts)

**2a.** Place the 4ft long Floor Block Ends provided on both ends of the floor alongside existing floor bearers as shown below.

**2b.** Fix together by screwing the Floor. Blocks at each end as shown. Use the screws provided and make sure the ends are fixed securely. 3 screws on each end will suffice.

= Drill Points using

screws provided as shown



4.0 x 70mm

Per Floor Block

#### 4ft LEFT SIDE PANEL

Place first panel on far of the shed floor as shown. (4ft wide blank panel)


#### **IMPORTANT**

Start Build point from Left to Right of Shed as shown on the diagram.



#### **4FT LEFT SIDE PANEL**

- **3a.** Place the 4ft panel against the far side of the shed floor. Make sure the panel stands firmly on the Heavy Duty Post (Floor Block)
- **3b.** Now prepare the other 4ft Blank Panel in order to create an 'L' shape in the corner with the two panels.
- **3c.** DO NOT fix the panels at this stage to the floor. This is because you need to leave room for adjustements in the final stages of the shed build.



## STEP • 5

#### **4ft REAR PANEL**

Fix 4ft Wide Blank Sections, Create a Corner for Balance.



#### **4ft REAR PANEL**

4a. Place a 4ft blank panel side as shown below. Repeat this step for all larger sheds. Please use reference on left for additional sections required according to

**4b.** Screw the panels alongside the framework as shown in Diagram 4b.

your shed size.

Not all Summer Sheds will have the same panel arrangment. Please Ensure that the 4ft Panels are central for all builds.



#### **4ft REAR PANEL**

Fix 4ft Wide Blank Section **Back Panel 4ft Section** 




#### **4ft REAR PANEL**

**5a.** Now place a blank 4ft panel side as shown. Repeat this step for all other sheds. Please use reference on above for correct sections required according to your shed size.

#### **INFORMATION**

Repeat Step 4, making sure that the back panel sizes corresponds with the floor size.



= Drill Points using screws provided as shown

### **2ft REAR PANEL**

Fix 2ft Wide Blank Section Back Panel 2ft (Right)



#### **2ft REAR PANEL**

#### **INFORMATION**

All of the Sheds, no matter the length or depth will have the 4ft back section located in the centre of the summer shed.

**6a.** Place the 2ft panel side against the corner of the back 2ft floor as shown making sure the panel is sitting firmly on the shed floor and the side meeting the framework of the back 4ft blank panel.

**6b.** Fix the panels together with screws as shown in diagram. You may require some supports to keep the frame upright whilst building longer sheds.



## STEP • 7

#### 4ft RIGHT SIDE PANEL

Now attach Right Side Panel (4ft wide section)



#### **4ft RIGHT SIDE PANEL**

= Drill Points using

screws provided as shown



panel as shown below. Screw sections together as shown in diagram 7a.

**7a.** Place the 4ft Right side

**7b.** Check that all the frames are correctly fixed and screwed together from the sides. Use more screws to strengthen if necessary.



**DO NOT screw the standing panels down to the floor just yet.** Leave room for adjustments when the final frame is fitted.



### **FRONT DOOR PANEL**

Attach Door Front Panel (4ft Door Panel)



#### **FRONT DOOR PANEL**

**8a.** Now place the 4ft Door Panel as shown. Fix together with screws to the right side panel framework.

#### **DID YOU KNOW?**

Door panels can be placed anywhere a 4ft panel is, this counts for window panels too.



## STEP •9

## FRONT WINDOW PANEL

Attach Second Front Window Panel (4ft Window Panel)



**9a.** Use the RED areas below as reference to the joining points of the final panel. Note the 4ft section should fit perfectly to continue the front section.

#### **DID YOU KNOW?**

Window panels can be placed anywhere a corresponding panel is. This counts for the door panel also.



**9b.** Place 4ft window panel as shown and fix in place at the meeting points with screws. Fix the panel sides with 3 screws.



## FRONT WINDOW PANEL

Attach First Front Panel (2ft Window Panel)




#### **2ft FRONT WINDOW PANEL**

**10a.** Place the 2ft window Panel on the right as shown. Fix together with screws to the right side panel framework as shown in diagram 8a.

**DO NOT screw the standing panels down to the floor just yet.** Leave room for adjustments when the final frame is fitted.

screws provided as shown



Sheds will have a 2ft Window Panel.

Per WindowPanel

## **STEP • 11**

#### **SIDE PENT ANGLE TOPS**

Now attach all the 4ft Side Tops of Pent Shed End Panels. (Over the top of both side panels).




#### **4ft SIDE PENT ANGLE TOPS**

**11a.** Place the right and left Pent Angle Tops as shown below. Make sure the higher ends are at the front of the shed as shown in the diagram below.

**11b.** Adjust the panels so that the tounge & groove are fixed together in place correctly. Use a hammer to lightly tap in to the grooves to create a perfect fit.

11. Attach the sections down by screwing through the inner frameworks of both panels.



#### **PENT FRONT TOPS**

Place the front tops of shed in relation to the fronts panels



#### **PENT FRONT TOPS**

**12a.** Place the Pent Front Top sections in place. Use the corrisponding sized tops with the correct sections. Make sure the correct section is placed on top of the correct front panel only as shown in the diagram.

**12b.** Adjust the panels so that the tounge & groove are fixed together in place correctly. Use a hammer to lightly tap in to the grooves to create a perfect fit.



= Drill Points using screws provided as shown

**12c.** Attach the sections down by screwing through the inner framework of both panels.



4.0 x 70mm

Per Front Top

## **STEP •13**

#### **SIDE & CORNER STRIPS**

Hide the panel edges. Cover the framework & seams.



#### **SIDE & CORNER STRIPS**

**13a.** Use all the side/corner strips to finish off the shed, by covering any exposed framework and the panel joining seams.

#### INFORMATION

The Corner Strips cover all panel edges. Remeber to attach these to the exterior back panels too.



#### **PENT ROOF PANELS**

Place First roof section. Repeat for all Roof Panels (4ft, 2ft)

#### **PENT ROOF PANELS**

screws provided as shown

14a. Place the 4ft x 4ft roof section in place. Repeat this stage for models as shown below. Repeat placing the roof panels corresponding to the panel size for the Floor Front an Rear.



#### INFORMATION

The Roof Panels are placed ontop of the appropriate front Panel, making sure that the sizes corrispond correcly.

> **14b.** Screw the roof panel down as shown in diagram 16b.

> > Per Roof Panel



## **STEP • 15**

## **PENT ROOF OVERHANGS**

Place First Overhang Section. Repeat for all **Roof Overhangs** (4ft, 2ft)

#### **PENT ROOF OVERHANGS**


**15a.** Place the 2ft Roof Overhang over the top of 2ft window panel. The overhang should fit between the frame work.

15b. Screw the Frame work of the overhang into the roof panel frame work from inside of the Summer shed.



#### **INFORMATION**

The Roof overhangs only fit into the clearance above the front panel that corresponds with the same sized overhang.



#### **PENT ROOF ADD-ON**

Fix Both Add-ons Inplace. (Left and Right)



## **STEP •17**

#### ATTACH THE ROOF FELT


Use the felt lengths provided.



#### **PENT ADD-ON**

**16a.** Place the Add-on touchin the appropriate side of the Roof Overhang (See Diagram below).

**16b.** Use Screws to secure the Add-ons to the Overhangs, making sure taht they sit flush to the front of the overhang.



**ROOF FELT** 







**17a.** Apply the roof felt as shown. Apply lower levels first to create correct rain run off positions.

**17b.** Using a hammer, tack down the felt with the tacks provided in a neat fashion.



**17c.** Trim down excess felt with a stanley knife. Remember to overlay the 1st felt to avoid rain leaks.

**17d.** Tuck and fold edges neatly and tack in place to hide any loose edges. Check that all areas are covered and there are no holes to avoid any rain water getting through your felt roof.







= Drill Points using screws provided as shown

#### **ATTACH FELT STRIPS**

Create the Final Roof Edges. Final steps finishing o

Final steps finishing off the roof.



#### **FELT STRIPS**

**18a.** Using the felt strips provided cover the edges of the roofs and ends of the roof felt. You will need to measure these and saw to fit to your requirements and create the perfect roof finish as shown below.

**18b.** Drill in the felt strips as shown on front and back of the shed to finish the roof off. Use the framework of the roof blocks to screw the felt strips down to. The felt strips will give your shed a neat finish for the roof and hide any overhang areas of the roof felt.



## **STEP • 19**

#### **DIAMOND CAPS**

Add the Finishing Touch. (Optional)



#### **DIAMOND CAPS**



Congratulations



Timber is a naturally grown product and may shrink and warp when dried out, timber is a porous material which can absorb water. Although all of our buildings come pressure treated we strongly advise the building is re-treated with an oil/spirit based treatment inside and out to make the timber water repellent and to preserve the quality and life of the product.

